

Template

1 Mark Latch Centre Line (☞)

87 mm

2 Mark Vertical Centre Line (☞)

Lock backset 60 or 70 mm

3 Cut Out Template

4 Adhere Templates on Door and Mark Holes

5 Drill Holes per Template

