



1. Adjustment of clearance between hinge jamb and door stile: Loosen screws (B) and (C).
2. Adjustment of door height: Loosen screws (B), (C), and adjust screw (A).
3. Centering door: Loosen screws (B) and (C).
4. Adjustment of closing speed: -Two regulating valves (D) and (E).

- (clockwise arrow) decrease closing speed.
- (counter-clockwise arrow) increase closing speed.
- Valve (D): control closing range 180°-15°
- Valve (E): control closing range 15°-0°
- 5. Adjustment of spring tension (F):
- (clockwise arrow) increase spring tension
- (counter-clockwise arrow) decrease spring tension

