Follow these steps to get your lock set up and ready to use using the application.

You can use the app to set up your lock step-by-step and access installation videos!

1 Download the app! Just search for "Schlage Sense" in the App Store or on Google Play.

Once you connect your lock to your app, the manual programming functions will be disabled and any access codes will be deleted.

Be sure to accept any available firmware upgrades.

The app will alert you to upgrades and walk you through the process.

Schlage Sense
App Icon

The Schlage Sense app works on iPhone, iPad, and iPod touch with iOS 9.3 or later or devices with Android 5.0 or later.

HomeKit is a trademark of Apple Inc. Google Play and the Google Play logo are trademarks of Google Inc. Android is a trademark of Google Inc.

» DON'T WANT TO USE THE APP?
Go to page 7 of the Schlage Sense User Guide located in the black envelope included in your demo mount box for manual programming instructions.

2 Pair your lock with your iOS device or Android smartphone.

Pair your lock using the Schlage Sense app for easy management.

Showroom Setup Note:

Unless your showroom plans to incorporate this Schlage Sense Smart Deadbolt into a larger display demonstrating other home automation components controlled by Apple HomeKit, we suggest you select setup via the Schlage System when prompted by the Schlage Sense App for a method of lock management during this step. The Schlage System supports the Schlage Sense app for iOS and Android smartphones, and virtual keys for admin and guest users.

3 Add access codes to your lock.
After adding your lock to your home, use the app to add codes to unlock your lock. Tap on the "people" icon, then "Access Codes."

4 Configure the alarm and other lock features.
The Schlage Sense Smart Deadbolt includes many features that you can configure using the Schlage Sense app.

5 Send virtual keys.
Share access with administrators and guests in the Schlage Sense app by tapping on the "people" icon, then "Virtual Keys".

If you set up your lock with Apple HomeKit, you will see "HomeKit Users".

Advanced features ideal for in person demos of the Schlage Sense Smart Deadbolt.

### Programming Code and Default Access Codes

The programming code and default access codes are located on one sticker, and the HomeKit setup code is located on the other sticker.

Front of the user guide
(Schlage Sense User Guide located in the black envelope included in your demo mount box for manual programming instructions.)

Back of the lock
You must remove the alarm from the door to see these stickers.